

A - ENGINE/VIN ID

1998 ENGINE PERFORMANCE

MODEL IDENTIFICATION

MODEL IDENTIFICATION

MODEL	BODYCODE	(1) ENGINE	ENGINE ID	FUEL SYSTEM	IGNITION SYSTEM
Achieva	N	2.4L (LD9)	T	SFI	IDI Magnetic
Achieva	N	3.1L (L82)	M	SFI	DIS Magnetic
Aurora	G	4.0L (L47)	C	SFI	DIS Magnetic
Bonneville	H	3.8L (L36)	K	SFI	C(3)I Hall Effect
Bonneville	H	3.8L (L67)	1	SFI (2)	C(3)I Hall Effect
Camaro	F	3.8L (L36)	K	SFI	C(3)I Hall Effect
Camaro	F	5.7L (LS1)	G	SFI	DIS Magnetic
Catera	V	3.0L (L81)	R	SFI	DIS Magnetic
Cavalier	J	2.2L (LN2)	4	SFI	DIS Magnetic
Cavalier	J	2.4L (LD9)	T	SFI	IDI Magnetic
Century	W	3.1L (L82)	M	SFI	DIS Magnetic
Corvette	Y	5.7L (LS1)	G	SFI	DIS Magnetic
Cutlass	N	3.1L (L82)	M	SFI	DIS Magnetic
DeVille (3)	K	4.6L (LD8) (4)	Y	SFI	DIS Magnetic
DeVille (3)	K	4.6L (L37) (4)	9	SFI	DIS Magnetic
Eighty Eight	H	3.8L (L36)	K	SFI	C(3)I Hall Effect
Eldorado	E	4.6L (LD8) (4)	Y	SFI	DIS Magnetic
Eldorado	E	4.6L (L37) (4)	9	SFI	DIS Magnetic
Firebird	F	3.8L (L36)	K	SFI	C(3)I Hall Effect
Firebird	F	5.7L (LS1)	G	SFI	DIS Magnetic
Grand Am	N	2.4L (LD9)	T	SFI	IDI Magnetic
Grand Am	N	3.1L (L82)	M	SFI	DIS Magnetic
Grand Prix	W	3.1L (L82)	M	SFI	DIS Magnetic
Grand Prix	W	3.8L (L36)	K	SFI	C(3)I Hall Effect
Grand Prix	W	3.8L (L67)	1	SFI (2)	C(3)I Hall Effect
Intrigue	W	3.5L (LX5)	H	SFI	(5)
Intrigue	W	3.8L (L36)	K	SFI	C(3)I Hall Effect
LeSabre	H	3.8L (L36)	K	SFI	C(3)I Hall Effect
LSS	H	3.8L (L36) 3.8L (L67)	K 1	SFI SFI (2)	C(3)I Hall Effect C(3)I Hall Effect

Lumina	W	3.1L (L82)	M	SFI	DIS Magnetic
Lumina	W	3.8L (L36)	K	SFI	DIS Magnetic
Malibu	N	2.4L (LD9)	T	SFI	IDI Magnetic
Malibu	N	3.1L (L82)	M	SFI	DIS Magnetic
Metro	M	1.0L (LP2)	6	TBI	Magnetic
Metro	M	1.3L (L72)	2	SFI	DIS Magnetic
Monte Carlo	W	3.1L (L82)	M	SFI	DIS Magnetic
Monte Carlo	W	3.8L (L36)	K	SFI	DIS Magnetic
Park Avenue	C	3.8L (L36)	K	SFI	C(3)I Hall Effect
Park Avenue	C	3.8L (L67)	1	SFI ⁽²⁾	C(3)I Hall Effect
Prizm	S	1.8L (LV6)	8	SFI	DIS Magnetic
Regal	W	3.8L (L36)	K	SFI	C(3)I Hall Effect
Regal	W	3.8L (L67)	1	SFI ⁽²⁾	C(3)I Hall Effect
Regency	H	3.8L (L36)	K	SFI	C(3)I Hall Effect
Riviera	G	3.8L (L67)	1	SFI ⁽²⁾	C(3)I Hall Effect
Saturn	Z	1.9L (LL0)	7	SFI	DIS Magnetic
Saturn	Z	1.9L (L24)	8	SFI	DIS Magnetic
Seville	K	4.6L (LD8) ⁽⁴⁾	Y	SFI	DIS Magnetic
Seville	K	4.6L (L37) ⁽⁴⁾	9	SFI	DIS Magnetic
Skylark	N	3.1L (L82)	M	SFI	C(3)I Hall Effect
Sunfire	J	2.2L (LN2)	4	SFI	DIS Magnetic
Sunfire	J	2.4L (LD9)	T	SFI	IDI Magnetic

(1) Engine code is stamped on engine block. See ENGINE CODE LOCATION table.

(2) Supercharged engine.

(3) Includes Concours and D'Elegance.

(4) Northstar engine.

(5) Information not available at time of publication.

VIN DEFINITION

VIN Definition

1	G	6	K	D	5	2	B	X	W	U	2	0	0	0	0	1	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

1 Indicates Nation of Origin.
 2 Indicates Manufacturer.
 3 Indicates Vehicle Division.
 4 Indicates Carline Body Code.
 5 Indicates Carline/series (Sales Code).
 6 Indicates Body Type.
 7 Indicates Restraint System.
 8 Indicates Engine ID.
 9 Indicates Check Digit.
 10 Indicates Model Year.
 11 Indicates Assembly Plant.
 12-17 Indicates Plant Sequential Number.

Fig. 1: VIN Definition

MODEL YEAR VIN CODE APPLICATION

VIN Code	Model Year
T	1996
V	1997
W	1998

ENGINE CODE LOCATION

ENGINE CODE LOCATION ⁽¹⁾

Engine Code	Location
LD8	On right front of engine, on rocker cover, OR on right front of engine block, forward of transmission extension.
LD9	On engine block, near oil filter, OR on left rear of engine, on bellhousing flange, OR On top front of engine block, near timing chain.
LL0	On left rear side of engine.
LN2	On left side of engine block, under exhaust manifold, OR on left rear of engine, on bellhousing flange.
LP2, LS1 & LV6	On left rear of engine block, on bellhousing flange.
LX5	(2)
L24	On left rear side of engine.
L36	On left side of engine, on rocker cover, OR on left rear of engine, on bellhousing flange.
L37	On right front of engine, on rocker cover, OR on right front of engine block, forward of

	transmission extension.
L47	On right front of engine, below cylinder head, OR on left front of engine, below cylinder head.
L67	On left front of engine, below cylinder head, OR on left rear of engine, on bellhousing flange.
L81	On left rear of engine, on bellhousing flange.
L82	On left rear of engine, on oil pan, OR on right side of engine, on rocker cover, OR on left rear of engine, on bell housing flange.
(1) See ENGINE in the <u>MODEL IDENTIFICATION</u> table for engine code location prefix (RPO).	
(2) Information not available at time of publication.	